

50*72mm

正面

i6 HR Smart Bracelet User Manual

Product parameters

Body Size: 49.0*19*10mm Wristband Size:252mm
Weight:17.8g
Screen:OLED
Battery:Built-in rechargeable lithium battery
Battery capacity : 75 mAh
Bluetooth:Bluetooth 4.0, working range 10~15m
Waterproof level: IP67
Working condition:-20~60 ℃
System requirement:
IOS8.0 or above
Android 4.4 or above, Bluetooth 4.0

Put on your smartband

Put on the smartband, wear appropriately when you feel comfortable (as shown in the figure).



Gesture Control

Methods of displaying screen: touch screen ,raise hand,turn over the wrist.



Function Icon



Touching

Functions	Operation
Turn on	Long press the screen
Turn off	Touch screen icon to ,click on the screen to switch ,then long press
Switching first-level directory	Slide the screen up or down
Switching secondary directory	Click on the screen
Confirmation	Click on the screen
View and delete message	Switch to interface , click screen to view the message Switch to the interface you want to delete the information, long press the screen
Heart Rate Monitor	Switch to the time display, click screen to
Enter sports	Switch to interface , click on the screen to select the type of motion After selecting the exercise, press the screen, the motion icon flashes means to enter the motion

Dial switch	Slide the screen to interface , click screen to , long press the screen, click switch dial style, long press the screen after selecting style
View walking data	Switch to the time display, click screen, view the number of steps , calories
Turn on the No Disturb	Switch to interface , click screen to , then long press the screen, After the No Disturb mode is started, will be displayed at the top of time interface on the homepage to prompt the No Disturb mode has been started.
Turn off the No Disturb	Switch to interface , click screen to , then long press the screen
Schedule Alarm Clock	Set in the Zeroner Health App

Application download

Search "Zeroner Health" on App Store, Google Play, or scan the QR code below to download the App and install it.



反面

Registration: Open the "Zeroner Health" App and log in if you have an account, or register a new account.

After a successful connection, time and motion data will be synced, Sleep monitoring, Message push, Call remind will turn on.

Charging

Please charge the bracelet for 45 minutes before using . Please press the back of bracelet which shows "OPEN" to make the host depart from the strap , then take out the host. Insert the host face down to a 5V/1A USB port for charging.



Activity/Sleep track

Equipped with a variety of sensors within the bracelet, worn on the wrist can easily identify and record the movement and the sleep status and data.

Pair the bracelet and Zeroner Health App , then you can view the previous day's sleep data in the App.

FAQ

Q: When connecting with App, the data SYNC is finished but the time on the device displays incorrectly.
A: Restart the bracelet and try data SYNC again.

Q: Why my bracelet has no Call ID Display?

A: **Android:** After being connected with bracelet with App, please allow "Zeroner Health" to visit calls, SMS, contacts and keep "Zeroner Health" running in background. If there are security softwares on your phone, set up the software "Zeroner Health" as "trust".
iOS: If there's no Call ID Display, please restart your mobile and reconnect the smartband. When it is connected, please wait until the phone pops up "Bluetooth pairing request" and click "pair", then the Call ID Display function comes.

Q: The bracelet icon shows the Bluetooth was connected, but the App cannot SYNC data?

A: It is caused by the Bluetooth of the phone in general. Please switch off the App first, restart the Bluetooth and repair. If the above step does not work, please restart your phone and try again.

More questions, please refer to the instructions for using in the Zeroner Health App.

Precautions

Prolonged exposure may cause skin irritation or allergic to some users. If you find any skin redness, swelling, itching or other allergic symptoms, please discontinue to use or wear it over clothing. Continue to use, even after the symptoms subside, it may make the symptoms recur even worse. If symptoms persist, please consult your doctor.

- This product contains electronic components which may cause injury if not done correctly.
- This product is not for diagnosis, treatment or prevention purposes.
- In driving or other potentially dangerous situations due to distractions, do not view call notifications or other data.
- This product is not a toy. Do not allow children or pets touch your products and devices . This product contains small parts that may cause smothering interest rate risks.

Nursing and wear Considerations

- Periodically clean, especially the parts in contact with the skin. Use a clean, moist cloth.
- Keep the band away from hot water and Non-toxic, but not contact with the acid-base .
- Wear loosely, to ensure that the air circulation.
- Remove the product from time to time, in order to clean, but also let the skin freely.
- Do not open the housing or demolition.
- If the display is broken, do not use.
- This product and its battery contains substances may be harmful to the environment, but also may be due to damage caused by improper handling or operation.
- Do not place the product in the washing machine or drying machine.
- Do not expose your product to extremely high or low temperatures.
- Do not sweat in the sauna or steam room to use the product.
- Do not make the product for a long time by the direct sunlight.
- Do not place the product in a fire process. The battery may explode.
- Do not use abrasive cleaners to clean the product.

- If the product gets wet, do not charge.
- If you feel product in the heat, remove it.

Built-in Battery Precautions

- Your product is equipped with built-in battery, the user can not replace. Product damage, or attempt to open the product will void the warranty and could pose security risks.
- Use certified by a recognized test computer charging treasure or power to charge the battery.
- Charge the battery in accordance with the instructions in this guide.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.